

York Serial Numbers ID

FROM HISTORY TO OCTOBER 2004

X X X X 9 9 9 9 9 9

6 DIGITS

SEQUENCED NUMBERS

Plant	
A	Addison
B	Blackville
C	Canada
D	Medina
E	Elyria
M	Mad'ville
N	Norman
W	Wichita
X	Mexico
Y	York

Month	
A	Jan.
B	Feb.
C	Mar.
D	Apr.
E	May
F	June
G	July
H	Aug.
K	Sept
L	Oct.
M	Nov.
N	Dec.

Year Assembled			
A	1971	A	1992
B	1972	B	1993
C	1973	C	1994
D	1974	D	1995
E	1975	E	1996
F	1976	F	1997
G	1977	G	1998
H	1978	H	1999
J	1979	J	2000
K	1980	K	2001
L	1981	L	2002
M	1982	M	2003
N	1983	N	2004
P	1984	P	2005
R	1985		
S	1986		
T	1987		
V	1988		
W	1989		
X	1990		
Y	1991		

TYPE OF ITEM

M=Mfg. Basic Unit
 P=Purchased Basic Unit
 S=Mfg. Low Side Item
 T=Purchased Low Side Item
 Y=Mfg. Accessory
 Z=Purchased Accessory
 O=Filler

KO	1960
LO	1961
MO	1962
NO	1963
PO	1964
RO	1965
SO	1966
TO	1967
VO	1968
WO	1969
XO	1970
AO	1971
BO	1972
CO/CM	1973

* Started 4 letters prefix.

D FOR ESG WAS EAST YORK PLANT

Coleman / Evcon Serial Numbers ID (Only Wichita Units)

X X X X 1 2 3 4 5

5 Digits sequenced Numbers

1992 to date: month of manufacture
 1991 back is Year of manufacture

1992 to date: Year of manufacture
 1991 back is month of manufacture

DUCANE SERIAL NUMBERS

Last 4 numbers

SB968615

86 = year
 15 = week

NEW SERIAL NUMBER NOMENCLATURE

1 2 3 4 5 6 7 8 9 10 (Position)
 N 0 L 4 1 2 3 4 5 6

Position # 3

Date Code: Month

A	Jan	G	July
B	Feb	H	Aug
C	Mar	K	Sep
D	Apr	L	Oct
E	May	M	Nov
F	June	N	Dec

Sequential Numbers (6)

Position # 2 & 4

Date Code: YEAR of Manufacture

Position #2 3rd digit of year of manufacture

Position #4 4th digit of year of manufacture

Example:

Year	Position #2	Position #4
2004	0	4
2005	0	5
2006	0	6
2007	0	7
2008	0	8
2009	0	9
2010	1	0

You must enter the "0" as a zero.

Position # 1

MANUFACTURING PLANT

N	NORMAN
W	WICHITA
A	APODACA
S	SOURCE ONE